


TWISTER II



PER:
FOR:

AZBE (E)




AZ6


AZ7


AZ8

CAVERS (F)

OPTIONAL



D741446ZB

Tracer point TE11
Tastatore TE11
Taster TE11
Palpeur TE11
Palpador TE11
Palpador TE11




D741447ZB

Cutter FE11
Fresa FE11
Fräser FE11
Fraise FE11
Fresa FE11
Fresa FE11

PER:
FOR:

CISA (I)




CS48

OPTIONAL



D741430ZB

Tracer point TE03
Tastatore TE03
Taster TE03
Palpeur TE03
Palpador TE03
Palpador TE03



D741431ZB

Cutter FE03
Fresa FE03
Fräser FE03
Fraise FE03
Fresa FE03
Fresa FE03




TWISTER II



PER:
FOR:

CISA (I)



CS144

CS146 CS70

CS62P CS62

CS70P CS115

CS116P CS139


CS139P CS140

CS141

CS145

NEW ASTRAL - ASIX

OPTIONAL



D722724ZB

Adaptors
Adattatori
Adapters
Adaptateurs
Adaptadores
Adaptadores

OPTIONAL



D741430ZB

Tracer point TE03
Tastatore TE03
Taster TE03
Palpeur TE03
Palpador TE03
Palpador TE03




D741431ZB

Cutter FE03
Fresa FE03
Fräser FE03
Fraise FE03
Fresa FE03
Fresa FE03

PER:
FOR:

ELZETT (H)



EL9

OPTIONAL



D741430ZB

Tracer point TE03
Tastatore TE03
Taster TE03
Palpeur TE03
Palpador TE03
Palpador TE03



D741431ZB

Cutter FE03
Fresa FE03
Fräser FE03
Fraise FE03
Fresa FE03
Fresa FE03




TWISTER II



PER:
FOR:

FICHET (F)




STANDARD



D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04




D741433ZB

Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR:

FTH (F)



OPTIONAL



D741430ZB

Tracer point TE03
Tastatore TE03
Taster TE03
Palpeur TE03
Palpador TE03
Palpador TE03




D741431ZB

Cutter FE03
Fresa FE03
Fräser FE03
Fraise FE03
Fresa FE03
Fresa FE03

PER:
FOR:

ISEO (I)



STANDARD



D741128ZB

Tracer point TE01
Tastatore TE01
Taster TE01
Palpeur TE01
Palpador TE01
Palpador TE01



D741127ZB

Cutter FE01
Fresa FE01
Fräser FE01
Fraise FE01
Fresa FE01
Fresa FE01



TWISTER II




PER:
FOR:

JIS (E)



JS5P

OPTIONAL




D701664ZB
Adaptors
Adattatori
Adapters
Adaptateurs
Adaptadores
Adaptadores

STANDARD




D741432ZB
Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04



D741433ZB
Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR:

KABA (CH)



KA1

8

LÅSBOLAGET (S)

OPTIONAL




D741430ZB
Tracer point TE03
Tastatore TE03
Taster TE03
Palpeur TE03
Palpador TE03
Palpador TE03



D741431ZB
Cutter FE03
Fresa FE03
Fräser FE03
Fraise FE03
Fresa FE03
Fresa FE03


PER:
FOR:

KABA (CH)



KA8

OPTIONAL




D710008ZB

Adaptors for KABA-Micro
Adattatori per chiavi KABA-Micro
Adapters für KABA-Micro Schlüssle
Adaptateurs pour clés KABA-Micro
Adaptadores para llaves KABA-Micro
Adaptadores para chaves KABA-Micro

OPTIONAL



D741487B
Tracer point TE13
Tastatore TE13
Taster TE13
Palpeur TE13
Palpador TE13
Palpador TE13



D741488B
Cutter FE13
Fresa FE13
Fräser FE13
Fraise FE13
Fresa FE13
Fresa FE13




TWISTER II



PER:
FOR:

MCM (E)




MC10R

OPTIONAL



D741476ZB

Adaptors
Adattatori
Adapters
Adaptateurs
Adaptadores
Adaptadores



OPTIONAL



D741436ZB

Tracer point TE06
Tastatore TE06
Taster TE06
Palpeur TE06
Palpador TE06
Palpador TE06




D741437ZB

Cutter FE06
Fresa FE06
Fräser FE06
Fraise FE06
Fresa FE06
Fresa FE06

PER:
FOR:

MCM (E)



MC9

OPTIONAL



D741442ZB

Tracer point TE09
Tastatore TE09
Taster TE09
Palpeur TE09
Palpador TE09
Palpador TE09



D741443ZB

Cutter FE09
Fresa FE09
Fräser FE09
Fraise FE09
Fresa FE09
Fresa FE09

OPTIONAL



D741444ZB

Tracer point TE10
Tastatore TE10
Taster TE10
Palpeur TE10
Palpador TE10
Palpador TE10



D741445ZB

Cutter FE10
Fresa FE10
Fräser FE10
Fraise FE10
Fresa FE10
Fresa FE10

STANDARD



D741128ZB

Tracer point TE01
Tastatore TE01
Taster TE01
Palpeur TE01
Palpador TE01
Palpador TE01



D741127ZB


Cutter FE01
Fresa FE01
Fräser FE01
Fraise FE01
Fresa FE01
Fresa FE01



TWISTER II



PER: **MUL.T.LOCK (IL)**
FOR:



MTK13R
MTK15R
 7X7
MTK13RAP
MTK15RAP
 7X7 (66)

OPTIONAL




D741446ZB
Tracer point TE11
Tastatore TE11
Taster TE11
Palpeur TE11
Palpador TE11
Palpador TE11



D741447ZB
Cutter FE11
Fresa FE11
Fräser FE11
Fresa FE11
Fresa FE11

PER: **MUL.T.LOCK (IL)**
FOR:



MTK1
MTK2P
MTK3P


STANDARD



D741128ZB
Tracer point TE01
Tastatore TE01
Taster TE01
Palpeur TE01
Palpador TE01
Palpador TE01



D741127ZB
Cutter FE01
Fresa FE01
Fräser FE01
Fraise FE01
Fresa FE01
Fresa FE01



MTK10RP
MTK4RPX
MTK12RP
 Junior
MTK4P
MTK4RP
MTK7RP
MTK8RP
MTK9RP

OPTIONAL



D741440ZB
Tracer point TE08
Tastatore TE08
Taster TE08
Palpeur TE08
Palpador TE08
Palpador TE08



D741441ZB
Cutter FE08
Fresa FE08
Fräser FE08
Fraise FE08
Fresa FE08
Fresa FE08




TWISTER II



PER:
FOR:

MOTTURA (I)



GVY1R

DEFENDER

OPTIONAL



D741446ZB

Tracer point TE11
Tastatore TE11
Taster TE11
Palpeur TE11
Palpador TE11
Palpador TE11




D741447ZB

Cutter FE11
Fresa FE11
Fräser FE11
Fraise FE11
Fresa FE11
Fresa FE11

PER:
FOR:

SEA (CH)



SEB1 SEB2 SEB3

SEA 23 SEA SEA 3
SEA 20 SEA 2

EZCURRA (E)

OPTIONAL



D741448ZB

Tracer point TE12
Tastatore TE12
Taster TE12
Palpeur TE12
Palpador TE12
Palpador TE12



D741449ZB

Cutter FE12
Fresa FE12
Fräser FE12
Fraise FE12
Fresa FE12
Fresa FE12

OPTIONAL



D741430ZB

Tracer point TE03
Tastatore TE03
Taster TE03
Palpeur TE03
Palpador TE03
Palpador TE03




D741431ZB

Cutter FE03
Fresa FE03
Fräser FE03
Fraise FE03
Fresa FE03
Fresa FE03

for SEB1 - SEB3 only
solo per SEB1 - SEB3
Nur für SEB1 - SEB3
Seulement pour SEB1 - SEB3
Solo para SEB1 - SEB3

PER:
FOR:

SECURITAL (I)



GVY1R

Psei

OPTIONAL



D741436ZB

Tracer point TE06
Tastatore TE06
Taster TE06
Palpeur TE06
Palpador TE06
Palpador TE06



D741437ZB

Cutter FE06
Fresa FE06
Fräser FE06
Fraise FE06
Fresa FE06
Fresa FE06




TWISTER II



PER:
FOR:

STS (E)




STS5



STS6

OPTIONAL



D741476ZB

Adaptors
Adattatori
Adapters
Adaptateurs
Adaptadores
Adaptadores



OPTIONAL



D741430ZB

Tracer point TE03
Tastatore TE03
Taster TE03
Palpeur TE03
Palpador TE03
Palpador TE03




D741431ZB

Cutter FE03
Fresa FE03
Fräser FE03
Fraise FE03
Fresa FE03
Fresa FE03

PER:
FOR:

TESA (E)




TE4
T10


TE4R

OPTIONAL



D741446ZB

Tracer point TE11
Tastatore TE11
Taster TE11
Palpeur TE11
Palpador TE11
Palpador TE11




D741447ZB

Cutter FE11
Fresa FE11
Fräser FE11
Fraise FE11
Fresa FE11
Fresa FE11

PER:
FOR:

TESA (E)




TE5
T80


TE7
T60

OPTIONAL



D741430ZB

Tracer point TE03
Tastatore TE03
Taster TE03
Palpeur TE03
Palpador TE03
Palpador TE03



D741431ZB

Cutter FE03
Fresa FE03
Fräser FE03
Fraise FE03
Fresa FE03
Fresa FE03




TWISTER II



PER:
FOR:

ZADI (I)



ZD25

OPTIONAL



D741434ZB

Tracer point TE05
Tastatore TE05
Taster TE05
Palpeur TE05
Palpador TE05
Palpador TE05





D741435ZB

Cutter FE05
Fresa FE05
Fräser FE05
Fraise FE05
Fresa FE05
Fresa FE05

PER:
FOR:

BMW (D)




HU59

HU63

HUF (D)
TIBBE (D)

HU58AP

OPTIONAL



D701664ZB

Adaptors
Adattatori
Adapters
Adaptateurs
Adaptadores
Adaptadores

STANDARD



D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04




D741433ZB

Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR:

BMW (D)



BW9MH

OPTIONAL



D741434ZB

Tracer point TE05
Tastatore TE05
Taster TE05
Palpeur TE05
Palpador TE05
Palpador TE05



D741435ZB

Cutter FE05
Fresa FE05
Fräser FE05
Fraise FE05
Fresa FE05
Fresa FE05




TWISTER II



PER:
FOR:

FORD (EU)




OPTIONAL



D741450ZB

Adaptors for FO19P-FO20P keys
Adattatori per chiavi FO19P-FO20P
Adapters für FO19P-FO20P Schlüssel
Adaptateurs pour clés FO19P-FO20P
Adaptadores para llaves FO19P-FO20P
Adaptadores para chaves FO19P-FO20P




OPTIONAL



D741434ZB

Tracer point TE05
Tastatore TE05
Taster TE05
Palpeur TE05
Palpador TE05
Palpador TE05




D741435ZB

Cutter FE05
Fresa FE05
Fräser FE05
Fraise FE05
Fresa FE05
Fresa FE05

PER:
FOR:

FORD (EU + USA)



IMPORTANT!


Key blank to be applied to the original remote control (the remote control includes the transponder chip)

OPTIONAL



D741409ZB

Code attachment
Dispositivo a codice
Code-Vorrichtung
Dispositif à code
Dispositivo a código
Dispositivo por código



STANDARD

D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04




D741433ZB

Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR:

HONDA (J)



OPTIONAL



D741434ZB

Tracer point TE05
Tastatore TE05
Taster TE05
Palpeur TE05
Palpador TE05
Palpador TE05



D741435ZB

Cutter FE05
Fresa FE05
Fräser FE05
Fraise FE05
Fresa FE05
Fresa FE05



TWISTER II



PER:
FOR:

HONDA (J)



HON66GP


HON66T5
HON66T6
HON66T14
HOV01T5

STANDARD



D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04




D741433ZB

Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR:

HUF (D)



HU100T12

HU100T

HU100BT12

OPEL

HU100AT12

STANDARD



D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04




D741433ZB

Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR:

HUF (D)



HU101...

STANDARD



D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04



D741433ZB

Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04




TWISTER II



PER:
FOR:

HUF (D)




HU92RP

OPTIONAL



D727645ZB

Adaptors A16 for HU92RP keys
Adattatori A16 per chiavi HU92RP
Adapters A16 für HU92RP Schlüssel
Adaptateurs A16 pour clés HU92RP
Adaptadores A16 para llaves HU92RP
Adaptadores A16 para chaves HU92RP




STANDARD



D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04




D741433ZB


Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR:

HUF (D)



HU83T5



HU83T




HU107T

STANDARD



D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04



D741433ZB

Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04




TWISTER II




PER:
FOR:

MERCEDES (D)



HU41P
HU41AP

HU55P



HU61AP




HU64P

HU64T
HUF (D)

HU65AP

OPTIONAL



D726291ZB

Adapters for MERCEDES keys
Adattatori per chiavi MERCEDES
Adapters für MERCEDES Schlüssel
Adaptateurs pour clés MERCEDES
Adaptadores para llaves MERCEDES
Adaptadores para chaves MERCEDES

STANDARD



D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04



D741433ZB


Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04



TWISTER II



PER:
FOR: **MERCEDES (D)**




HU39P

HU39T

HU40P

HUF (D)

OPTIONAL



D701664ZB

Adaptors
Adattatori
Adapters
Adaptateurs
Adaptadores
Adaptadores

STANDARD



D741432ZB


Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04



D741433ZB

Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR: **OPEL-VAUXHALL (D)**



HU43T9
HU43AT9
HU43T
HU43TGM


HU43P

OPTIONAL



D741429ZB

Code device
Dispositivo a codice
Code-Vorrichtung
Dispositif à code
Dispositivo a código
Dispositivo por código



STANDARD




D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04



D741433ZB

Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04



YM27T2

YM27P







TWISTER II



PER:
FOR:

SAAB (S)




 **YM30BP**
  **YM30P**
  **YM30T5**
VALEO-YMOS (D) **YMOS (D)**

OPTIONAL



D741427ZB

Adaptors
Adattatori
Adapters
Adpteurs
Adaptadores
Adaptadores



STANDARD



D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04




D741433ZB

Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR:

TRW SIPEA (I)



 **SIP22LP**
  **SIP29T**
  **SIP18T**
  **SIP22KP**
 **SIP22T5**

OPTIONAL



D741434ZB

Tracer point TE05
Tastatore TE05
Taster TE05
Palpeur TE05
Palpador TE05
Palpador TE05



D741435ZB

Cutter FE05
Fresa FE05
Fräser FE05
Fraise FE05
Fresa FE05
Fresa FE05



TWISTER II



PER:
FOR: **TOYOTA (J)**




TOY40BT4
TOY40
TOY40P
TOY40AP




TOY48P

TOY48BT4
ARISTO

STANDARD





D741432ZB
Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04



D741433ZB
Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR: **VALEO (F)**





 
VA2T14 VA6 ...

STANDARD



D741432ZB
Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04



D741433ZB
Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04




TWISTER II




PER:
FOR:


VOLVO (S)




HU56RAT2




HU57RP





HU56RP

STANDARD



D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04




D741433ZB

Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR:

ZADI (I)





ZD30T5

OPTIONAL



D741434ZB

Tracer point TE05
Tastatore TE05
Taster TE05
Palpeur TE05
Palpador TE05
Palpador TE05



D741435ZB

Cutter FE05
Fresa FE05
Fräser FE05
Fraise FE05
Fresa FE05
Fresa FE05




TWISTER II



PER:
FOR:

AUDI (D)
FORD (D)
PORSCHE (D)
SEAT (E)
SKODA (CZ)
VOLKSWAGEN (D)



HU66T1	HU66AT6
HU66T5	HU66T10
HU66T6	HU66T15
HU66AT5	HU66BT15
HU66CT5	HU66BT1
HU66DT5	HU66PL
HU66CT6	HU66T5L
	HU75T
	HU103T


HUF (D)
WITTE (D)

OPTIONAL



D741427ZB

Adaptors
Adattatori
Adapters
Adaptateurs
Adaptadores
Adaptadores



STANDARD

D741432ZB

Tracer point TE04
Tastatore TE04
Taster TE04
Palpeur TE04
Palpador TE04
Palpador TE04





D741433ZB


Cutter FE04
Fresa FE04
Fräser FE04
Fraise FE04
Fresa FE04
Fresa FE04

PER:
FOR:

CENTURY (USA)	CEN5T (10)
CHICAGO (USA)	CH16T (9.2) CH17T (10)
L&F (GB) ERA (GB) AGA (E)	
MERONI (I)	MER22T (9.50) MER25T (9.50)
P.CORTELLEZZI (I)	PC12T (9.60) PC12TP (9.60) PC15T (9.60) PC15TP (9.60)
SILCA (I)	SLC1TP (9.60) SLC2TP (9.60)
SIDLEEN (USA)	SD3T (9.50)



OPTIONAL



D741428ZB

Device for tubular keys
Dispositivo per chiavi tubolari
Vorrichtung für Steckschlüssel
Dispositif pour clés tubulaires
Dispositivo para llaves tubulares
Dispositivo para chaves tubulares

OPTIONAL



D741438ZB

Tracer point TE07
Tastatore TE07
Taster TE07
Palpeur TE07
Palpador TE07
Palpador TE07



D741439ZB

Cutter FE07
Fresa FE07
Fräser FE07
Fraise FE07
Fresa FE07
Fresa FE07

